



S-100

초밥성형기

sushi shaping machine



S-100

**INSTRUCTION
MANUAL**

[사용 설명서]

manufacturer :

SM FOOD MACHINE

(신미식품기계)

WEBSITE :

www.sinmi.co.kr

주요부 상세설명 [description]

<모델명 : S-100>



작동 순서 [sequence of operation]

1. 호퍼와 성형틀에 식용유를 분사한다. (식용유 : 물 = 5 : 5)
2. 호퍼에 밥을 투입후 작동 스위치를 ON 시킨다.
3. 속도 볼륨을 조정하여 속도를 조절한다.
4. 밥 압력을 확인하고, 압력 볼륨을 조정한다.

1. It sprays cooking oil in the hopper and on the shaping frame.
(cooking oil : water = 5 : 5)
2. Put the rice in the hopper, and then turn on the start switch.
3. Control the speed to adjust the speed volume.
4. check the rice pressure, and adjust the pressure volume.



작업시 유의사항 [precautions]

1. **밤 공급 가이드 롤러**

- 밤을 알맞은 압력으로 공급시켜주며, 재질은 테프론입니다.
- L,R 이 정해져 있으므로 확인후 끼워 주십시오.

2. **조밤 성형틀**

- 조밤을 성형시켜주며, 재질은 테프론입니다.
- L,R 을 확인후 끼우고, 틀을 빼고 끼울때는 스위치를 조작하여 , 성형틀이 일자가 되었을때 끼우시면 편리합니다.

3. **밤 공급 갈퀴**

- 뒤쪽에서부터 기어의 흑색,백색,흑색,백색을 확인하여 봉을 빈틈사이가 없이 밀착시켜 제인과 돌린다.

4. **밤방울 일정하게 하는 센서 (센싱거리는 정가운데 위치시킨다.)**

- 구멍으로 일자드라이버를 이용하여 시계방향으로 돌릴시 거리는 멀어진다. (한 칸의 거리는 약 15mm)

5. **전원 플러그 (퓨즈 내장)**

- 퓨즈 교환시 기계의 뒷면에 전원 플러그를 분리하십시오.
- 콘센트 하부에 퓨즈 홀더가 있습니다.
- 기계의 메인등이 켜지지 않을 때는 콘센트 하부의 홈을 일자 드라이버로 빼내어 확인하여 주십시오.
- 스페어 퓨즈가 같이 들어 있습니다.
(단, 볼트는 풀지 마십시오.)

1. Guide roller

- It serves to supply the rice to the appropriate pressure.
- Its material is Teflon.
- L,R is set, and please insert after confirmation.

2. Shaping frame

- It molds a rice, and its material is Teflon.
- L,R is set, and please insert after confirmation.
- When you take apart or insert the frame, match up the groove with overhang by operating the switch.

3. Rake

- Check the black, white, black, white from the rear gear in close contact without gaps between the rods and bitten by a chain.

4. Sensor for a constant amount of rice

- If you turn an adjuster clockwise with a flat head screwdriver in a hole of the adjuster, distance is away.
(distance of one space : approximately 15 mm)

5. Limit switch

- When you open the door, the power is cut off.

6. Sensor for detecting rice

- When the rice is detected on the disc, it is stopped.

7. Power plug (internal fuse)

- Disconnect the power plug on the back of the machine during the fuse replacement.
- There is a fuse holder in the bottom of outlet.
(It contains an extra fuse.)
- When the main lamp does not light, check the fuse.
(It is not necessary to loosen the bolt.)